

**Consolette base**

**Astro and XTL  
dash mount mobile**

**Use CAB-00209B**

**Trunk mount**

**Astro and XTL**

**Use CAB-00247B**

**Click** on the plus sign on the **Radio Configuration**

Go to the Radio **Wide selection**

Select the **“TX Audio Per Mode”** tab

In the **“External Mic”** section in the middle of the page, uncheck all 3 of the AGC boxes

On the right side, set the **“Analog Fixed Gain”** to +12 db

On the right side, set the **“Digital Fixed Gain”** to +12 db

On the right side, set the **“Securenet Fixed Gain”** to +12 db

If this is a dash mount radio, go to the **Advanced Tab**, the **“AUX PTT”** should be set to **“AUX\_MIC”**.

If this is a trunk mount radio and your using the DB25 connector for the interface point, go to the **Advanced tab**, the **“AUX PTT”** should be set to **“AUX TX”**

***SyTech Corp.***

**RCU I/O Type Ten**

CAB-00209B\_txt

03/23/2013