

**XTL med power trunk mount
XTL-5000 high power**

PM-1500

Use CAB-00247B

Click on the plus sign on the **Radio Configuration**

Go to the Radio **Wide selection**

Select the “TX Audio Per Mode**” tab**

In the “External Mic**” section in the middle of the page, uncheck all 3 of the AGC boxes**

On the right side, set the “Analog Fixed Gain**” to +12 db**

On the right side, set the “Digital Fixed Gain**” to +12 db**

On the right side, set the “Securenet Fixed Gain**” to +12 db**

Go to the **Advanced tab, the “**AUX PTT Audio Source**” should be set to “**AUX_TX**”.**

SyTech Corp.

RCU I/O Type Ten

CAB-00247B_txt

03/23/2013